

SERVICE TIPS

Installing FlexxiFloat™ Nylon Tail | Crop Lifters

FlexxiFloat™ Crop Lifters are now shipped with the tail removed so that you have the option to use the crop lifter with or without the tail. The tail can provide additional lift in lighter crop situations but is not recommended when harvesting heavy crops.

To install the tail on your crop lifter:

1. Tighten the rail of the crop lifter in a vise.
2. Insert the tenon of nylon finger into the slot at the back of the arm, with the rounded step of the tail fitting into the groove. Insert the self-tapping screw into the hole on the other side of the arm. (Refer to Photo 2.)
3. Using a drill or impact outfitted with an extension and a $\frac{5}{16}$ " socket, drill the screw into the tail.

